

# Report

- **Date:** January 25, 2024
- **Location:** UCL
- **Participants:** Alexis, Tabitha

## Objectives

- Investigate and mitigate EEG noise caused by LRA-related EMI.
- Test actuator amplitude mapping.
- Discuss silicone moulding setup and process.

## Activities

### 1. EEG Noise Testing

#### Setup

- At the hospital, Tabitha set up the EEG system with electrodes immersed in a saline solution.
- The Bsense device was configured to send periodic impulses to the LRA actuators.
- Two experimental conditions were tested:
  - i. LRA actuators positioned close to the EEG electrodes ( $\approx 2\text{--}3\text{ cm}$ ), without direct contact with the saline solution.
  - ii. LRA actuators in direct contact with the saline solution.

#### Observations

- **Condition 1 (LRA close, no contact):**  
No visible noise was observed on the EEG signals when the LRA actuators were activated.
- **Condition 2 (LRA in contact with saline):**  
Significant noise appeared on the EEG signals during LRA activation.

## Hypothesis

- The observed EEG noise is likely caused by direct electrical coupling between the LRA metal casing and the conductive medium (saline / body), rather than radiated EMI.

## Actions Taken

- **Shielding:** Although shielding did not appear to be the primary issue, the LRA metal casing was connected to a grounded shielding wire as a precautionary measure.

## Next Steps

- Test the system on-body with the shielding connection in place.
- If noise persists, electrically isolate the LRA casing from the skin using a non-conductive layer (e.g. tape).
- If insulation resolves the issue, design a dedicated non-conductive enclosure for the LRA actuators.

## 2. Amplitude Mapping

### Setup

- Connected the Bsense device to a PC via serial.
- Used a Python script to sweep PWM duty cycle values sent to the LRA actuators.
- Assessed resulting vibration amplitude using a finger as a subjective proxy.

### Observations





- Above approximately **0.5 duty cycle**, no perceptible increase in vibration amplitude was observed.

### Actions Taken



- Documented the signal generation and amplitude mapping process (see [LRA\\_Signal\\_Generation.md](#)).
- Created a simulation of the LRA response as a function of PWM duty cycle and excitation frequency.

The model predicts a linear relationship between duty cycle and vibration amplitude (see figures below).

# Simulation Result



## Simulation Result



- Given the actuator's **1.8 V RMS rating** and a **3.3 V supply**, maximum usable amplitude is expected around **~70% duty cycle**; beyond this, saturation is likely.
- Firmware was updated (no PC-side changes required) so that the full user-facing duty cycle range (0–100%) maps internally to **0–50% actuator duty cycle**.
- PWM frequency was increased to **46.875 kHz**.

## Next Steps

- Validate the amplitude mapping using an objective measurement setup (test bench with accelerometer).

## 3. Silicone Moulding Discussion

Discussed the silicone moulding workflow for the grasping sensor with Tabitha.

### Process

- Mix silicone components A and B thoroughly (1:1 ratio).
- (Optional) Apply a thin layer of release agent (e.g. Vaseline) to the 3D-printed mould to facilitate demoulding.
- Pour the silicone mixture into the mould.

4. *(Optional)* Degas in a vacuum chamber to remove air bubbles introduced during mixing (recommended but not strictly required).
5. Allow to cure at room temperature for **4–6 hours**.
6. Carefully demould the cured silicone part.

## Next Steps

- Purchase silicone: [Smooth-On Ecoflex 00-30](#).
- 3D print moulds for the sensor components.