


Tap Impulse Generation

Tap impulses are generated by driving the LRA using a parametrised PWM-based excitation signal. The impulse is fully defined by three parameters: **frequency**, **amplitude**, and **duration**.

V_{ib} : - Amplitude = α (nu)

- Frequency = $\frac{1}{T}$ (Hz)

- duration = D (ms)



Parameters

Amplitude


- Defines the effective drive amplitude applied to the LRA.
- As the microcontroller cannot output a true analog voltage, amplitude control is implemented using **PWM (Pulse Width Modulation)**.
- The user-facing amplitude parameter is normalised to the range **0–1**.
- Internally, this value maps to a **PWM duty cycle of 0–50%**, ensuring the actuator remains within its safe operating voltage range.

Frequency

- Defines the excitation frequency (in **Hz**) of the signal driving the LRA.
- Vibration strength increases as the excitation frequency approaches the LRA's mechanical resonance (\approx **230 Hz**).
- Frequencies far from resonance result in significantly reduced vibration amplitude due to the LRA's band-pass mechanical response.

Duration

- Defines the length of the impulse in **milliseconds**.
- The actuator is driven continuously at the specified frequency and amplitude for the duration of the impulse.



Parameter Encoding

Each parameter is encoded using **1 byte (8 bits)**, allowing compact transmission and deterministic decoding:

- **Frequency:**
 - Range: **0–255 Hz**
 - Resolution: **1 Hz per step**
- **Amplitude:**
 - Range: **0–1 (normalised)**
 - Resolution: **$1 / 255 \approx 0.00392$ per step**
- **Duration:**
 - Range: **0–255 ms**
 - Resolution: **1 ms per step**